

Wahoo Docks Captain's Chair - Side Mount

Assembly and Mounting Instructions



WHAT'S IN THE BOX

- a. (1) Chair Frame
- b. (2) Arm Rests
- c. (8) Arm Rest Mounting Bolts
3/16" x 1" Bolt/Locknut/Washers
- d. (1) Cup Holder
- e. (1) Fishing Rod Holder
- f. (4) Rod Holder Attachment Screws
3/4" Wood Screws
- g. (1) Mounting Bracket
- h. (1) Pedestal w/ Foot Rest
- i. (1) Pedestal Attachment Bolt
3/8" x 3 1/2" Bolt/Locknut/Washers
- j. (4) Long Mounting Bolt
3/8" x 3 1/2" Bolt/Locknut/Washers
- k. (4) Short Mounting Bolt
3/8" x 1 1/2" Bolt/Locknut/Washers

TOOL REQUIREMENTS

- (2) 9/16" Wrench
- (1) Power Drill
3/8" Drill Bit
- (1) Phillips Head Screwdriver
- (1) Clamp - optional



Bottom Detail
with Swivel Post

CHAIR ASSEMBLY

Attach Arm Rests (b) to Chair Frame (a) using the Arm Rest Mounting Bolts (c). Each Arm Rest can be attached on the left or right side depending on the desired location of the Cup Holder (d) or Fishing Rod Holder (e). After the arm rests are secure, slide the Cup Holder and Fishing Rod Holder into place, securing the Rod Holder with the Rod Holder Attachment Screws (f).

ATTACH MOUNTING BRACKET TO DOCK

Select a position on the outer frame of the dock where you'd like the Chair to be located. Position the Mounting Bracket (g) on the frame of the dock and drill four (4) 3/8" holes through the plate on the Mounting Bracket and the outer frame of the dock - it may be useful to use vice grips or another type of clamp to secure the Mounting Bracket to the dock frame while drilling the holes. If possible, holes should be about 1/2" from each corner but drilling into a secure location on the dock frame is most important. Fasten the Mounting Bracket to dock frame using either the Long Mounting Bolts (j) or Short Mounting Bolts (k), depending on the type of dock frame you have - use the bolt size that will best fit through the Bracket and dock frame. Place a Flat Washer onto a Bolt, insert the Bolt into one of the drilled holes and secure on the back side with a Flat Washer and a Locknut. Repeat for each hole so that the Mounting Bracket is secured with four (4) bolts.

SECURE PEDESTAL TO MOUNTING BRACKET

Slide Pedestal (h) fully into the tube of the Mounting Bracket, with the Foot Rest facing away from the dock toward the water. The pre-drilled hole in the Pedestal should line up with the pre-drilled hole in the receiving tube on the Mounting Bracket. Insert the Pedestal Attachment Bolt (i) into this hole, utilizing the flat Washers on either side, and secure with the Locknut.

ATTACH CHAIR

Slide the swivel post located on the underside of the chair seat into the receiver at the top of the Pedestal. Voila! Your chair is ready!

